

Fig. 1





Fig. 2a






Fig. 2b




Fig. 3




Fig. 4




Fig. 5




Fig. 6





Fig. 7

FIG. 8







FIG. 8A

FIG. 8B



Please enter your password

← Cancel

This figure shows a password entry screen. It features a large rectangular area with a horizontal line near the top. The text "Please enter your password" is centered. Below the text is a password input field containing three asterisks, followed by a key icon. In the bottom left corner, there is a "Cancel" button with a left-pointing arrow.

FIG. 8C

FIG. 8D

Incorrect Pass Word
Please try again

← Cancel

This figure shows a screen for an incorrect password. It has a similar layout to FIG. 8C, with a large rectangular area and a horizontal line near the top. The text "Incorrect Pass Word" and "Please try again" is centered. Below the text is a password input field containing three asterisks, followed by a key icon. In the bottom left corner, there is a "Cancel" button with a left-pointing arrow.






FIG. 8E

FIG. 8F



Please choose from the following Options	
1- Withdraw	Buy Money Order -5
2- Deposit	Wire-Transfer -6
3- Cash Check	Bill Payments -7
4- Cash Money Order	Buy Lottery Tickets, -8 Stamps & Phone Cards

FIG. 9



Choose Account

← 1. Checking

← 2. Saving

←

FIG. 10


FIG. 11

Withdraw
from Checking

← <input type="button" value="\$20.00"/>	<input type="button" value="\$100.00"/> →
← <input type="button" value="\$40.00"/>	<input type="button" value="\$200.00"/> →
← <input type="button" value="\$50.00"/>	<input type="button" value="Other"/> →

←

FIG. 11A



Withdraw
from Saving


\$500.00

← Cancel

Continue →

FIG. 12

FIG. 13



<u>Deposit</u> <u>into Checking</u>	
What would you like to deposit	
←	1. Cash
←	2. Check
←	3. Money Order
←	<div>Cancel</div>

FIG. 13A

FIG. 13B

<u>Deposit Check</u>	
<div>52</div> <div><div>\$675.52</div></div>	
←	<div>Cancel</div>
	<div>Continue</div> →


Please sign back of Check
When ready, insert into Scanner Slot.



FIG. 13C

FIG. 13D

69



<div>\$674.52 Will be deposited into your account.</div>
Please take your receipt Thank you...

FIG. 13E


FIG. 13F

<div><u>Deposit</u> <u>into Saving</u></div> <div>What would you like to deposit</div>
<div>⇐ 1. Cash</div> <div>⇐ 2. Check</div> <div>⇐ 3. Money Order</div>
<div>⇐ <div>Cancel</div></div>

Deposit Cash

You have inserted \$0.00

Please insert your \$\$ bills
into the bill acceptor slot....

 Cancel


Continue 

FIG. 13G





FIG. 13H

Deposit Cash

You have inserted \$ 20.00

Please insert your \$\$bills
into the bill acceptor slot....

 Cancel


Continue 


FIG. 13I


FIG. 13J

Deposit Cash

You have inserted \$ 65.00

Please insert your \$\$bills
into the bill acceptor slot....

 Cancel

Continue 





FIG. 13K

FIG. 14



Would you like to make another transaction?

Yes ➡

No ➡

FIG. 15A

FIG. 15B

Would you like to make another transaction ?

Yes

No

Cash Check

\$ 0.00


58

← Cancel

Continue →

FIG. 16

FIG. 16A



Cash Check

\$ 90.00

← Cancel

Continue →

FIG. 16B

FIG. 16C

Please sign back of Check
When ready, insert into Scanner Slot.

← Cancel





FIG. 16D

FIG. 16DD






FIG. 16E

FIG. 16F

Cash Check

	\$40.00

70

← Cancel Continue →

The diagram shows a screen layout for a 'Cash Check' transaction. At the top, the text 'Cash Check' is underlined. Below it is a large rectangular area containing three smaller rectangular boxes stacked vertically. The bottom box contains the text '\$40.00'. A curved line with the number '70' points to this box. At the bottom of the screen, there are two buttons: 'Cancel' on the left and 'Continue' on the right. The 'Cancel' button has a left-pointing arrow to its left, and the 'Continue' button has a right-pointing arrow to its right.

Receive \$40.00

49.00 Will be deposited into your account.

Please take your receipt
Thank you....


FIG. 16G

FIG. 16H

Cash Check

Enter Amount of Check

Service Charge \$1.00



Cash A Money Order

\$100.00

← Cancel


Continue →

FIG. 17A

FIG. 17B

Please sign back of Money Order
When ready, insert into Scanner Slot

← Cancel



Sorry,
We Cannot Process This Money Order
Please Check With Your Financial
Institution

FIG. 17C

Purchase Money Order

Please enter information.

Pay To:

←

Cancel

FIG. 18

FIG. 18A

Purchase Money Order

Please enter information.

Pay To:

72

\$ 500.00

\$ 500.50


←

Cancel

Continue

→

FIG. 18B



\$ 500.50

Please Select a Method of Payment :

⇐ 1. Cash

Smart Card .4 ⇐

⇐ 2. Credit Card

Back to Money Order .9 ⇐

⇐ 3. Withdraw from my Account

⇐

Cancel

FIG. 18C

FIG. 18D

\$ 500.50 is withdrawn from your account.

Your Money Order is being
Printed
Please take your receipt
Thank you....

Wire Money

Please enter information, when done press 'Enter'

To:	<input type="text" value="JOHN DOE"/>		
Bank's Name	<input type="text"/>		
FED Routing Code (ABA#)	<input type="text"/>	<input type="text"/>	
ACCOUNT NUMBER	<input type="text"/>		

FIG. 19

FIG. 19A

Wire Money

Please enter information, when done press 'Enter'

To:	<input type="text" value="JOHN DOE"/>		
Bank's Name	<input type="text" value="FIRST AMERICAN"/>		
FED Routing Code (ABA#)	<input type="text"/>	<input type="text"/>	
ACCOUNT NUMBER	<input type="text"/>		

Wire Money

Please enter information, when done press 'Enter'

To:	JOHN DOE
Bank's Name	FIRST AMERICAN
FED Routing Code (ABA#)	7896654
ACCOUNT NUMBER	

← Cancel

FIG. 19B

FIG. 19C

Wire Money

Please enter information, when done press 'Enter'

To:	JOHN DOE
Bank's Name	FIRST AMERICAN
FED Routing Code (ABA#)	7896654
ACCOUNT NUMBER	987-87654

← Cancel

Wire Money

Please enter information, when done press 'Enter'

To:	JOHN DOE
Bank s Name	FIRST AMERICAN
FED Routing Code(ABA)	7896654
ACCOUNT NUMBER	987-87654

← Cancel

78

\$ 850.00


\$ 935.00

78a

Continue →

FIG. 19D

FIG. 19E



\$ 935.00

Please Select a Method of Payment:

⇐ 1. Cash

Smart Card .4 ⇐

⇐ 2. Credit Card

Back to Wire Transfer .9 ⇐

⇐ 3. Withdraw from my Account

⇐

Cancel

FIG. 19F

Pay Bills
\$ 0.60 per bill Service Charge

Select the bills you want to pay, follow instructions. When done, press Continue

<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;"><input type="checkbox"/> Phone</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;"><input type="checkbox"/> Electric</div> <div style="border: 1px solid black; padding: 2px;"><input type="checkbox"/> Gas</div>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px; text-align: right;">Cable <input type="checkbox"/></div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px; text-align: right;">Water <input type="checkbox"/></div> <div style="border: 1px solid black; padding: 2px; text-align: right;">Credit Card <input type="checkbox"/></div>	
<input type="button" value="Cancel"/>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Serv. Charge \$ 0.00</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-top: 2px;">\$ 0.00</div>	<input type="button" value="Continue >"/>

FIG. 20

FIG. 20A

Pay Bills
\$ 0.60 per bill Service Charge

Enter amount to Pay on your Phone bill
Select another bill to pay
When done, press Continue

<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;"><input type="checkbox"/> Phone \$129.67</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;"><input type="checkbox"/> Electric</div> <div style="border: 1px solid black; padding: 2px;"><input type="checkbox"/> Gas</div>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px; text-align: right;">Cable <input type="checkbox"/></div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px; text-align: right;">Water <input type="checkbox"/></div> <div style="border: 1px solid black; padding: 2px; text-align: right;">Credit Card <input type="checkbox"/></div>	
<input type="button" value="Cancel"/>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Serv. Charge 0.60</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-top: 2px;">\$130.27</div>	<input type="button" value="Continue >"/>

Please insert Phone bill into Scanner Slot





FIG. 20B

FIG. 20C


Pay Bills
0.60 per bill Service Charge

Enter amount to Pay on your Gas bill
Select another bill to pay
When done press Continue

<input type="checkbox"/> Phone	\$129.67	<input type="checkbox"/> Cable
<input type="checkbox"/> Electric		<input type="checkbox"/> Water
<input type="checkbox"/> Gas	\$45.22	<input type="checkbox"/> Credit Card



Serv. Charge



Please insert Gas bill into Scanner Slot

← Cancel

FIG. 20D

FIG. 20E

Pay Bills
\$ 0.60 per bill Service Charge

Enter amount to Pay on your Credit Card bill....
Select another bill to pay....
When done press Continue

← <input type="checkbox"/> Phone \$129.67	Cable <input type="checkbox"/> →
← <input type="checkbox"/> Electric	Water <input type="checkbox"/> →
← <input type="checkbox"/> Gas \$45.22	\$96.82 Credit Card <input type="checkbox"/> →

← Cancel

Serv. Charge \$1.80

\$273.51

Continue > →

\$273.51

Please Select a Method of Payment:

⇐ 1. Cash

Smart Card .4 ⇐

⇐ 2. Credit Card

Back to Bill Payment .9 ⇐

⇐ 3. Withdraw from my Account

⇐

Cancel

FIG. 20F


FIG. 20G

Please insert Credit Card bill into Scanner
Slot

⇐

Cancel

FIG. 20H



\$273.51 is withdrawn from your account

Your Bills are Paid
Please take your receipt
Thank you....

FIG. 20I

FIG. 20J

<input type="checkbox"/> Phone	Cable <input type="checkbox"/>
<input type="checkbox"/> Electric	Water <input type="checkbox"/>
<input type="checkbox"/> Gas	Credit Card <input type="checkbox"/>
<input type="button" value="Cancel"/>	Serv. Charge \$0.00
	Total \$0.00
	<input type="button" value="Continue >"/>


Purchase

Please check items to buy, enter quantity. When done press Continue

<input type="checkbox"/> Stamps \$6.50/booklet	
<input type="checkbox"/> Smart Card \$5.00/card	
<input checked="" type="checkbox"/> Phone Cards \$10.00/card	<input type="text" value="1"/>
<input type="button" value="Cancel"/>	<div><div>\$10.00</div><div>Continue</div></div>

FIG. 21

FIG. 21A



Purchase

Please check items to buy, enter quantity. When done press Continue

<input type="checkbox"/> Stamps \$6.50/booklet	
<input checked="" type="checkbox"/> Smart Card \$5.00/card	3
<input checked="" type="checkbox"/> Phone Cards \$10.00/card	1

← Cancel \$25.00 Continue

FIG. 21B

FIG. 21C

\$25.00

Please Select a Method of Payment:

← 1. Cash	Smart Card .4 →
← 2. Credit Card	Back to Purchase .9 →
← 3. Withdraw from my Account	

←

\$ 25.00

You have inserted \$ 0.00

Please insert your \$\$ bills
into the bill acceptor slot....

← Cancel

FIG. 21D

FIG. 21E

\$ 25.00

You have inserted \$ 20.00

Please insert your \$\$ bills
into the bill acceptor slot....

← Cancel

The screen displays a transaction amount of \$25.00 in a box at the top. Below it, a message reads "You have inserted" followed by a box containing \$21.00. The main instruction on the screen is "Please insert your \$\$ bills into the bill acceptor slot....". At the bottom left, there is a "Cancel" button with a left-pointing arrow.

FIG. 21F

FIG. 21G

The screen displays a transaction amount of \$25.00 in a box at the top. Below it, a message reads "You have inserted" followed by a box containing \$24.00. The main instruction on the screen is "Please insert your \$\$ bills into the bill acceptor slot....". At the bottom left, there is a "Cancel" button with a left-pointing arrow.

Please Take Your Merchandise
Please take your receipt
Thank you

FIG. 2IH

FIG. 2II

Purchase

Please check items to buy, enter quantity. When done press Continue

	Total
<input type="checkbox"/> Stamps \$6.50/booklet	
<input type="checkbox"/> Smart Card \$ 2.50/card	
<input type="checkbox"/> Phone Cards \$10.00/card	


Cancel

Grand Total

\$ 0.00

Continue

FIG. 22



Change Due


This machine can dispense CASH only in \$5 increments
We still owe you \$3.50
Please choose how you would like to receive that

⇐ 1. Credit To My Smart Card

⇐ 2. Deposit into My Bank Account

⇐

FIG. 23






FIG. 25